

INSTRUCTIONS

1

LAYOUT

Place mounting templates on flat surface. Line up templates along their baselines, then set spacing by aligning registration marks and tape templates together (see spacing tips next page).

2

MARKING

Place assembled template against surface where numbers are to be installed. Level template and tape to surface. Mark each drilling location and remove template.

3

DRILLING

Using a $\frac{3}{16}$ " bit, drill holes at marked locations to a minimum depth of $\frac{3}{4}$ ". Do not drill through template.

4

MOUNTING

Thread mounting rods into numbers. Place a spacer on each rod. Do a trial fit on mounting surface. Coat ends of threaded rods and fill holes with silicone caulk. Press rods into caulked holes. Spacers are optional but strongly recommended for best aesthetics.

5

CARE

Clean numbers with a soft cloth. Never use abrasives or harsh chemicals.

SPACING TIPS

When mounting your Neutra House Numbers, pay special attention to the space between numbers. The template's registration marks provide good spacing in most situations, but a few number combinations will need minor adjustments, for instance those including 4, 6, 7 and 9. The goal is to create spacing that is visually equivalent between numbers. To achieve that, adjust spacing before final assembly of template. Using the template grid lines as a guide, nudge numbers one unit at a time until you achieve a pleasing appearance.



* **QUESTIONS: 1.800.944.2233 OR WWW.DWR.COM**



ARTWORK, NEUTRAFACE FONT AND NUMBERS ©2018 HOUSE INDUSTRIES.
"NEUTRAFACE" IS A REGISTERED TRADEMARK OF HOUSE INDUSTRIES.