


HermanMiller

Paldoo Table Installation Instructions



Parts Included



A Paldoo Table Top
QTY 1 (only one top per package)



B Paldoo Leg QTY 3/4

⚠ WARNING

Failure to fully tighten legs could result in table failure, legs breaking or other damage.

⚠ WARNING


Heavy!
Exercise caution when lifting

How to assemble your paldao table

Step 1

1.1 Use 2 people to place table top onto clean protective surface, top down.


Caution: Do not roll the table top on it's edge to avoid damaging table top.



Step 2


2.1 Align leg over assembly hub and lower until internal threaded stud is inserted in center hole of attachment hub.

2.2 Screw the leg into the attachment hub until it cannot be tightened anymore and leg tight against the surface of the top.




Step 3

3.1 Repeat steps 2 and 3 until all legs are attached and tight.




Step 4

4.1 Use 2 people to rotate the table right side up in desired location.
Caution: Do not roll the table to upright position to avoid damage to the legs.



Paldao Coffee Table



Paldao Side Table