

FITTING ADJUSTMENT ON EDEL RANGE

DRAWER HEIGHT ADJUSTMENT on half extension drawer runners (right part of Media and Credenza)

Drawer height can be adjusted with turning the pin under the drawer.



DRAWER HEIGHT ADJUSTMENT on full extension drawer runners (left part of Credenza)

Drawer (shelf) height can be adjusted with turning the pin under the drawer.



SPACE ADJUSTMENT BETWEEN THE DOORS AND SIDE OF CARCASE on Credenza, Media and Console

The space between the doors and side of carcass can be adjusted with moving the plastic stopper in the groove of sliding mechanism (under the top). Allen key 2,5 should be used to untighten the screw.



SPACE ADJUSTMENT BETWEEN THE DOORS AND TOP OF CARCASE on Credenza, Media and Console

The space between the doors and top of carcass can be adjusted with turning plastic pin on back side (top) of the doors. Plastic mechanism is on left and right side of the door. A left door is possible to adjust on both sides. Right doors is possible to adjust only on right side (mechanism on left side is hidden behind the left doors).

