


IF POINT 1 IS LOWER THAN POINT 2
TURN POINT Ⓐ CLOCKWISE OR TURN
POINT Ⓒ CLOCKWISE

IF POINT 2 IS LOWER THAN POINT 1
TURN POINT Ⓓ CLOCKWISE OR TURN
POINT Ⓑ CLOCKWISE



MEDIA UNIT 70" (LINE TV 1800)